

## BUTTONS & PULL CORD STATIONS

Fully-featured digital I/O (input/output) control appliance  
The Buttons Station provides push button registration of nurse presence ( LED indication), or aide presence ( LED indication) at remote locations. The nurse/aide presence indicator unit can also be used to transfer nurse follower feature from room to room as nursing staff proceeds with rounds. Depressing the nurse presence registration button automatically transfers indication of all subsequent patient calls to the remote location of the nurse, as well as to the master station. Plug-in connectors provide for simple wiring.

### OPTIONS

- 2 Buttons and One Bed Cord Input
- 3 Buttons and 2 bed Cords
- 4 Buttons and 2 bed Cords
- 1 Button and 1 Pull Cord



### ALARM BUTTONS AND BED CORD

From One to Four Illuminated Buttons and Bed Cord interface with Plug-Out detection



### WIRED OR WIRELESS VERSIONS

Long range of up to several kilometers.



### LOCATION AND POSITIONING

When paired with ControlledCare Positioning buttons, the Stations can collect up to 2,000 beacons per positioning area.



### FRIENDLY WEB INTERFACE

Easy self-configuration and provisioning via the built-in web interface.



### ERROR REPORTING

Automatic error reporting through supervisory messages.



### INTERNAL ANTENNA BOOST MODE

Fully integrated internal antenna Boosted Spread Spectrum Mode



### STANDARD MOUNTING SIZES

Standard single, double or triple gang size Wall-In or Wall mount options



### BATTERY SUPERVISION

Automatic low battery reporting and supervisory reporting. (Wireless Version)



ControlledCare's Bed Station can be deployed wirelessly (battery operated) or wired. These bed side stations are commonly deployed near one or two beds (such as shared rooms.) The stations support call cords with wired attached buttons and display which resident or patient requested assistance.

### TYPICAL SCENARIOS

**Patient-Staff Alert:** To alert staff, a resident presses their call cord button which triggers a transmission to the ControlledCare Even Management Service. When the staff arrive in the room to assist they will press the Cancel button to clear the call.

**Staff Assist Alert:** The button is used by staff if they are in the room and need additional help. Pressing the button will send a Staff Assist notification to other staff with the proper room location. Or Check-in, Cleaning Required, General Info etc.

There are maximum 4 buttons, allow to have a combination of 2, 3 or 4 in total. All are LED lit in order to show the status and reason of the alarm. Any button can be customized for any required features.

There are three sizes available, all fit into standard gang boxes. Can be signaling only, Full Duplex Audio, Audio/Video, RFID for identification or embedding all.

Wireless version running from Li-Io 18650 battery or external source. Excellent wireless penetration through structures such as walls and floors.

Ultra-Low power consumption with 20,000-1,000,000+ messages over 5-10 years on a single battery

### FEATURES

- Single gange Size
- Push butt on and multi color LED for nurse presence indication
- Push button and yellow LED for aide presence indication  
Automatic nurse follower transfer
- Flame retardant (UL® 94V-0) plastic faceplate



[WWW.CONTROLLED CARE.COM](http://WWW.CONTROLLED CARE.COM)

#### CONTROLLED CARE SYSTEMS HEALTH SOLUTIONS

109 Rainside Road, Unit 305 M3A 1B2, Toronto, ON, Canada • Toll Free: 800.792.7137 • Phone: 416.623.5476  
sales@controlledcare.com • [www.controlledcare.com](http://www.controlledcare.com)